

ASSEMBLY AND INSTRUCTION MANUAL

MODEL 0318 BABOO

© 2018 KURT BEIER & KATI QUINGER



Functional chair with
two, one or ...




...without armrest(s)
and 360° rotary function




Simple handling
by sensor buttons

Attention! Safety note:

The base plate is plugged into a conical turning spindle.
For transportation it is absolutely necessary to lift up the
chair at the base plate.



360° rotary function:





Functions:

Sitting and lying functions:

The individual sitting and lying functions are controlled via the sideways placed capacitive sensor buttons.

- > A = Back moves backwards
- > B = Back moves upwards
- > C = Footrest moves downwards
- > D = Footrest moves upwards



Adjustment of head-rest:

1. To adjust the desired position grip the head-rest from the outside and pull it carefully towards yourself.
2. To obtain zero position pull the head-rest carefully beyond the top position towards yourself and fold it down into zero position.
3. From zero position you can easily snap the head-rest into desired position.

Attention!

The sensor buttons are always mounted on the left, the charging socket is always mounted on the right. (Direction decisive is always standing in front of the furniture).

